



FLEETHOSTER®
FUELING YOUR FLEET WITH INTELLIGENCE

GEOTAB®

Next Gen GO Anywhere™

Quick start guide

Rev. A1 – 09/2025



Warnings

⚠ **Professional installation required** - Installation of this product requires that the installer have sufficient technical knowledge and expertise for mobile device installation and integration into modern vehicles, i.e. Certified Geotab Installer certification or equivalent.

Read important related safety information and Limitations of Use following these installation instructions. Read and follow all instructions and warnings to prevent serious injury and/or vehicle damage.

WARNING! Some installations are not straightforward and must be completed by an Authorized Installer to ensure a secure installation. Some examples requiring professional installation from an Authorized Installer include if the device may not be fully secured and could vibrate loose, get knocked or if the installer questions their ability to complete a secure installation according to these instructions.

WARNING! Prior to Go Anywhere installation, read and follow important safety information including limitations of use located following these installation instructions. Always read and follow all safety information to prevent loss of vehicle control and serious injury.

WARNING! Do not attempt to install, reconfigure, or remove any product from a vehicle while the vehicle is in motion or otherwise in operation. All installation, configuration, or removal must be done only in stationary vehicles which are securely parked. Attempting to service devices while the vehicle is in motion could result in malfunctions or collisions, leading to death or serious personal injury.

WARNING! To prevent risk of fire or damage to the asset, the external power harness must be connected to an appropriately fused circuit. Failure to use a correctly fused power source can lead to an overcurrent condition, resulting in serious damage to the asset's electrical system and/or risk of fire.

CAUTION! The device may become hot to the touch during operation, particularly when externally powered in high-temperature environments. Exercise caution when handling the device after extended use to avoid the potential for minor burns.

CAUTION! To prevent equipment damage and ensure reliable operation, do not install the device where it may be exposed to corrosive chemicals or fuels. Such exposure can damage the housing and internal components, compromising the device's integrity and voiding the warranty.

WARNING! Keep away from children. The magnets can cause serious injury or death if ingested. The magnets are strong and may cause harm if mishandled. Always slide the magnets when trying to separate or join them to avoid personal injury or damage.

NOTE! Always get permission before you drill, and inspect the area to ensure no adjacent equipment will sustain any damage.

WARNING! To prevent risk of fire, explosion, or chemical leakage, use only Geotab-approved replacement batteries. The use of unauthorized or incompatible batteries will void the product warranty and can lead to device failure or a safety hazard.

WARNING! Do not use a battery that is leaking, damaged, or deformed. Handle compromised batteries with appropriate personal protective equipment to avoid chemical burns. Dispose of damaged batteries immediately according to local hazardous waste regulations.

WARNING! Do not short-circuit the battery terminals. Allowing the terminals to come into contact with metallic objects can cause rapid overheating, leakage, or explosion, resulting in serious injury or fire.

NOTICE: The Geotab GO Anywhere is a monitoring device and is not a failsafe anti-theft or life-saving system. Device functionality depends on factors including battery charge, available GPS and cellular coverage, and proper installation. Do not rely on this device for emergency situations or as the sole means of asset security.


Important safety information and limitations of use

You must always select the right Telematics hardware suitable for your specific installation environment and vehicle use.


For the latest version of the Limitations of Use, please visit: goo.gl/k6Fp0w.

NOTICE: This product does not contain any user-serviceable parts. Configuration, servicing, and repairs must only be made by an authorized reseller or installer. Unauthorized servicing of these products will void your product warranty.

In the box



x 1




x 3

1 Add assets

In MyGeotab, add your Next Gen GO Anywhere devices using the provided link:
<https://my.geotab.com/#addAssets>

2 Activate




Press the button on the device to begin activation. For optimal performance, ensure the device is in an area with good cellular coverage and a clear view of the sky for GNSS/GPS. An outdoor location is recommended.

LED State		What's going on?
	Slow flash	Activation in progress <i>Do not touch the device.</i>
	Fast flash for 15 seconds	The device is configured correctly and communicating <i>The device is healthy. No action required.</i>
	Flash every 15 seconds	No (or weak) cell service <i>Move asset to an area with cellular coverage. Press button to re-attempt activation.</i>
	x2 flash for 15 seconds	No GPS signal <i>Move device to be in sky view. Press button to re-attempt activation.</i>


NOTE: If activation is unsuccessful, the device will automatically retry. You can manually force a retry by pressing the device's button.

3 Mount

Ideal mounting location should have a clear view of the sky with minimal metal obstruction.




Option 1: Mounting with Screws




Option 2: Mounting with Magnets

NOTE: Magnets can be found in the ACC-GAMAG kit (purchased separately).



4 Validate

Validate your device using the Geotab installation tool. Navigate to <https://install.geotab.com/>



GEOTAB®

www.geotab.com

Geotab Next Gen GO[®] Anywhere[™] Support Document