



ADD-IN PROCESS

- The Support Manager will need to be added to the database that the cameras will be associated with
 - Support will add the FleetFlix API and Support User
 - Support will associate the database with the FleetFlix cameras
- The FleetFlix Add-in will need to be added:
 - Go to System Settings Add-ins New Add-in and then paste the code below
- The cameras will automatically populate inside their associated database
- If you are installing without a Telematics device the only difference will be that your Support Manager will add your cameras unique Geotab SN in the Vehicles Tab in Geotab
- The cameras are ready to install

FLEETFLIX ADD-IN CODE


```
"supportEmail": "support@fleethoster.com",
"version": "1.1",
"items": [
             "menuName": {
    "en": "FleetFlix"
               "svglcon": "https://fleetflixapp.blob.core.windows.net/addin/prod/fleetflix_icon.sv
"icon": "https://fleetflixapp.blob.core.windows.net/addin/prod/fleetflix_icon.svg",
               "menuld": "FleetFlixAlLink"
               "url": "https://fleetflixapg
"path": "FleetFlixAlLink/",
               "menuName": {
    "en": "Cameras"
              "url": "https://fleetflix.app.blob.core.windows.net/addin/orod/fleetflix-event.html", "path": "FleetflixAlLink/", "menuName": { }
                     "en": "Events"
               "icon": "https://fleetflixapp.blob.core.windows.net/addin/prod/events_icon.svg"
               "url": "https://fleetflixapp.blob.core.windows.net/addin/prod/fleetflix-recordine.html" "path": "FleetFlixAlLink/",
               "menuName": {
    "en": "Recordings"
              ),
"svglcon": "https://fleetflixapp.blob.core.windows.net/addin/prod/recordings_icon.svg"
"iron": "https://fleetflixapp.blob.core.windows.net/addin/prod/recordings_icon.svg"
"iron": "https://fleetflixapp.blob.core.windows.net/addin/prod/recordings_icon.svg"
               "url": "https://fleetflikapp.blob.core.windows.net/addin/prod/fleetflik-settinp.html",
"path": "FleetFlixAlLink",
"menuName":
"en": "Rules"
               "path": "FleetFlixAILink/",
               "menuName": {
    "en": "Coaching"
                "syglcon": "<u>https://fleetflixapp.blob.core.windows.net/addin/coaching_icon.syg"</u>,
               "page": "map",
"title": "FleetFlix Live",
"noView": false,
"mapScript": {
    "url": "https://flee
                "noView": false,
"mapScript": {
                      "url": "https://fleetflixapp.blob.core.windows.net/addin/prod/trip-addin/events/index.html"
               "page": "tripsHistory".
               "title": "FleetFlix Recordings",
"noView": false,
               "mapScript": {
  ,
solutionId": "fleetHosterFleetFlix".
```



Powered by cutting-edge AI technology, FleetFlix cameras actively detect risky driving events and unsafe behaviors, delivering real-time reminders to drivers on the road. This not only mitigates potential risks but also acts as a valuable tool for driver training. The camera seamlessly uploads events to the Geotab platform, providing a comprehensive overview for strategic decision-making. Stay ahead with real-time and accurate vehicle position information and operational data transmitted directly to the MyGeotab™ platform. FleetFlix Dash Cameras ensure that you have the insights you need for effective resource management. Experience the convenience of high-quality Live Streaming and video live view playback, making fleet management easier and more efficient than ever before. Elevate your fleet's safety and efficiency standards with FleetFlix Dash Cameras – where innovation meets reliability for a smarter and safer journey.

Logging In:


a) Please log into your my.geotab.com database



Navigating to the FleetFlix Add-In:

This will appear underneath "Add-Ins" once it has been added to your database. If not present, please immediately contact our support team for assistance.


a) This is done by selecting "Add-Ins" on the far left of your screen and clicking the drop-down arrow for "FleetFlix AI" then selecting "Cameras":



Cameras Dashboard:

This is the main FleetFlix AI Cameras page.

a) Here you will see a full list of the FleetFlix devices in your database:



- b) At the top of this page, you will see different tiles. Each tile breaks down the status of your devices
 - Total cameras: This lists the total number of devices you have.
 - Online, Standby, Offline: These list the total number of devices currently in each status.
 - Require Measurements & Require Calibration: These tiles let you know what devices currently need measurements entered, and what devices also need to be calibrated. If you need any assistance with this, please contact Fleet Hoster support.
 - Require Subscription, Require Serial Number, Require Firmware/Software Update, and Data Protection Tiles: These tiles are all for Fleet Hoster's visibility.

- c) Name: Underneath "Name" you will find some important status information for each device.
 - a) Name of the device
 - b) The serial number or Geotab device the camera is paired with
 - c) The status of the camera there are three types.
 - Online: this will be in green. It means the ignition is on & the vehicle is moving. The camera is actively recording when its in this state.
 - Standby: this will be in orange. It means the vehicle's ignition has been turned off and the camera will stay in standby mode for 30 minutes. So if at any time you need to gather footage/events, once the truck has been turned off, you have some time to download/view that footage.
 - Offline: this will be in red. During this state, the camera is not connected to the network, and it is not actively recording.

d) IMEI:

The IMEI is the number used to identify each device.


e) Current driver & License plate:

You will also see an option to assign a driver and license plate number to each device as well.

Live Stream:

To the far right of each device, you will see an option to view live stream footage.

- a) Clicking the dropdown arrow, you will see a few options:
 - Front Camera
 - Driver Camera
 - Auxiliary Cameras (if installed)



Front Camera:



Driver Camera:



Auxiliary Camera:



PLEASE NOTE!: We do not recommend constant live streaming as this will affect data usage for your device.


Individual Device Settings & Calibration Status:

Begin by clicking on the name of the device. Doing so will take you to your next screen: here you will see three sections: Profile, Rule Settings, and Measurements. If utilizing auxiliary cameras, you will also see Router Settings and Aux. Settings.

Profile:

This is where the specific information for each device is listed.


- a) IMEI: This is where the IMEI of the device is listed.
- b) Description: This is where you can name the device.
- c) Geotab vehicle: This is where you can pair your device with the appropriate Geotab vehicle, if GO9s are being utilized. If GO9s are not being utilized, please disregard.



Measurements:


Here you can input the measurements of your vehicle in order to accurately calibrate your camera:

- a) Width of vehicle
- b) Height from camera mount to ground
- c) Length from camera mount to front of vehicle




Rule Settings:

This page allows you to set your camera to capture different events:



a) 5 Options for Capturing Event Data:

- Off: this means you will not receive any notification for that rule.
- Event only: you'll receive just a notification that an event occurred.
- Short video: you'll receive a short video, 3 seconds before, 2 seconds after.
- Long video: you'll receive a long video, 5 seconds before, 5 seconds after.
- Snapshot: is just that, a snapshot/photo.




b) Types of Events:

- Button pushed: this button is available for the driver to push in the event of something important, such as an accident, etc. This creates a timestamp of the event. We recommend setting this one to "Video" with the assumption that if the driver is taking time to press this button, it is probably important.
- Camera blocked: this means there is something obstructing the camera lens. Please note this alert is only for the in-cab lens not the road facing. For this we recommend just a snapshot.
- Collision: this obviously triggers in the event of a collision. You can adjust the sensitivity for this.
- Driver distracted: this triggers when the driver's eyes have been off the road for 2 or more seconds.
- Driver facing camera: you can disable the in-cab camera. Whatever your company policy is will be fine here.
- Driver fatigue: for this the camera is looking for head nodding, heavy eyelids, if the driver's head rolls back, things like that to indicate that maybe the driver needs to pull over, take a break, etc.
- Driver Phoning: this triggers if the camera detects a phone in the driver's hands.
- Hard brake & hard cornering: these are both triggered by side-to-side movement.
 The sensitivity can be adjusted for these as well.
- Harsh acceleration: This will trigger if the driver accelerates faster than normal, again you can adjust the sensitivity.
- Lane departure: this feature allows the camera to tell you if the driver switches lanes without using turn signals, or if the driver is swerving. For this feature to work, the camera does have to be wired into the turn signal using the grey and pink wires. (Grey-left, Pink-right)

- Tailgate warning: this triggers if the driver is following the vehicle in front of them too closely. The sensitivity for this is the number of seconds before impact would be made. Again, you can adjust this.
- Trip snapshots: this enables the camera to take snapshots every 2 minutes on a trip, which will appear over in the MAPS section, which we'll get to in just a minute here. – Just a general note, but this does use quite a bit of data – so only use it if needed, otherwise, we recommend you leave it off.
- Record audio: this allows for the camera to record in-cab audio. Please note, you
 cannot hear audio when live streaming, you can only hear it once the footage is
 downloaded.
- Wakeup Sensitivity: If ignition is off and the camera experiences a G-Force against it, the camera will wake itself up to capture what caused that to trigger and stay in that mode until turned back off.
- Idle time: this is when the vehicle is not moving, but you need the camera to keep recording. For instance, if you had a concrete truck you need the vehicle to stay on to keep moving, but you don't need your camera to keep recording for that long, you can set that time limit here.
- Standby time: this is when the vehicle has been turned off and stays there for 30 minutes to allow access to footage that you may need before shutting down.
- c) Router Settings: This is where you will enter the SSID and password to pair your router to the main dash camera.



d) Aux Settings: This is where you will see the specific auxiliary cameras listed, along with a photo of their most recent trip.



Bulk Editing Rules:

Here is where you can edit the rules for all of your devices at one time.
a) Do so by clicking on the "FleetFlix AI" drop down menu and choose "Rules":




Fleet Rules Settings:

This page looks the same as the individual rule settings page for each device, however there are a few differences to note.

a) Types of FleetFlix devices

At the top of the page, you will see three different FleetFlix device types. Please ensure the correct device type is chosen for your fleet/devices you are trying to edit in bulk. If there are ever any questions about this, please contact our support team.

- FleetFlix AI+ Pro
- FleetFlix Lite Pro
- FleetFlix Lite
- b) Fleet Override: This button allows you to apply a rule setting to your entire fleet of devices at once.
- c) In CAB Alert: This button allows you to enable the device to emit an audio alert to the driver each time a rule is broken.
- d) Display in miles per hour in subtitles: this option allows the M/HR to be included in the video text overlay at the top of each event and recording. **ONLY FOR FF LITE & FF LITE PRO DEVICES**
- e) Once all desired settings are chosen, hit "Save" in the top left corner. You will then receive a message stating that the changes will be made effective when the device goes on its next trip.



PLEASE NOTE!: Events only stay stored on the cloud for 4 months before being overwritten.

Geotab Rules:


This is found at the top of the page as well. If you have Geotab devices, this is where you can apply your Geotab rules in bulk for your devices, if applicable



Events:

This is where you can view all events triggered for your devices.


a) In order to do this, simply navigate to the "FleetFlix AI" drop down menu and choose "Events":



Options:


Once on the "Events" page, you will see an "Options" box populate. You can search by the following parameters:

- a) Date period
- b) Group
- c) Camera (name)
- d) IMEI
- e) Event type



Viewing Events:

Once all desired parameters are selected, simply select "Apply changes" and all applicable events will populate.



- a) Request Media: To view an event select "Request Media". The event will then show "Queued" until it downloads and is available to view. This typically takes a few minutes.
- b) View Media: If an event is set to "snapshot" or "short/long video", you will be able to retrieve media for the event. If the event is set to "event only" or "off", you will not receive media for the event.



Populated Media:


Once you select "View Media", a box will appear with both the front and driver camera views.

a) Video text overlay: This appears at the bottom of each event and includes the date, time, longitude/latitude, and speed. You will see a few options for viewing the media. If a video, you can play/pause.




Recordings:


In order to view recording footage, simply navigate to the "FleetFlix AI" drop down menu and choose "Recordings".



a) Select your camera from the dropdown menu.




- b) Camera type:
 - Front only populate road facing footage
 - Rear only populate in-cab footage
 - All populate both Front and Rear footage
- c) Date: choose your desired date to view.




d) Available time:

- Bolded times there are available recordings during these times.
- Greyed out times there are no available recordings during these times.



e) Load Records: Once the desired parameters are selected, choose "Load Records". This will populate all available recordings.



f) Request Media: You will see an option to "Request Media". Once selected, you will see a "Queued" message while the footage downloads. This typically takes 1-2 minutes. Once the footage downloads, you will see an option that says "View Media":



g) View Media: Once you select "View Media" a video box will populate for either the Road facing or Driver facing camera. Each recording has a video text overlay as well:




678.759.2544 | sales@fleethoster.com | www.fleethoster.com

h) Downloading Footage: From here you can view then download the footage if desired. Once downloaded it is stored on your computer for your records. If you have in-cab audio enabled, you can hear the audio through downloaded recordings as well.


PLEASE NOTE!: Your device must be "online" or in "standby" mode in order to request and view recording footage. If the device is "offline" it will stay in the queued stage until back online.

Audit Logs:

This is where you can view any changes that are made in the FleetFlix Add-In a) In order to view the "Audit Logs" for the FleetFlix Add-In, simply navigate to the main "Cameras" page and at the top select "Audit Logs":




b) Once selected, you will be taken to a page that lists all changes made in your FleetFlix Add-In. It details the device edited, the user who made the change, along with a date and time stamp. There is an "Options" filter at the top you can utilize to view a specific date range or specific edit type:




Alarms Report:

In order to receive notifications about any events that are triggered for your devices, you will need to set these up underneath the "Alarms Report", found at the top of the main "Cameras" page.




a) My Notifications: Once selected you are taken to a page that will list all exiting notifications.



b) Notification Rules: In order to set what notifications, you want to receive, choose "Notification Rules" at the top of the page and you will be taken to a page listing all notifications enabled.

c) Add Rules: In order to add a rule to be notified about, simply select "Add Rules" at the top of the page. Once selected, you will be prompted to add a rule.



d) Adding a rule:


• Type: Camera events or Camera diagnostics

Rule: specific ruleAlarm: ON/OFF


Email alert: ON/OFF

• Email interval: choose how often you receive the email for the rule chosen


• Once the parameters are selected for your rule, choose "Save" in the top left corner.




e) Email settings: To set up an email notification, navigate back to the Notification Rules page and choose "Email Settings". This page will show you all existing email recipients. To add an email, choose "Add recipients" at the top of the page.



f) Email settings: This is where the existing email recipients will be listed.





g) Add Recipients: Once selected, you will be prompted to add the recipients email information and choose the specific rules they want to receive notifications about.



h) Updating Email Settings: Once added, choose "Save" in the top left corner and you will be taken back to the "Email Settings" page. Next to each email, you will see a few options:

- Delete: this removes a recipient
- Update: this option allows you to apply specific rules to that recipient. Here you can choose your desired rules to subscribe to notifications for.






Coaching:

Coaching BI is a feature exclusive to FleetFlix that allows fleet managers to better coach their drivers on different driving behaviors to optimize fleet safety and efficiency.

a) This can be found by navigating to "Coaching" underneath the FleetFlix Add-In.



b) If you have any questions about this or would like more information about how to utilize this tool, please contact our support team.

